



WitchDoctor's Billet Specialties LLC
King Pin Polished License Plate Mount
www.buywitchdoctors.com

Attention:

This is an install at your own risk item. If you are not capable of installing it successfully then we suggest you take this item to a professional shop.

Part # LPM-KPSS

- 1- Polished license plate mount
- 1- Led plate frame
- 2- Heat shrink bullet connectors
- 1- Hole plug

1-Remove your saddle bags, rear seat, side covers and rear fender struts before you begin .



2-Remove the bolt on each side of the driver seat and remove seat. (Fig.1)



3-Remove the 4 bolts that hold the rear fender on. (Fig. 2)

2



5-Slowly lift the rear of the fender upward to gain access to the bolts and wiring for the stock license plate mount. Get someone to hold the fender or prop it up so you can work on it.



Remove the cover plate by the tail light that protects the wires to gain access to the license plate connectors. Unplug the connectors and set the plate aside. Splice on the bullet connectors to the new LED frame. Heat the connectors to shrink seal them.

Check out our part# KP-FL fender liner to protect your wiring !



Cut the rubber gasket where indicated by the blue line. You will reuse it on the new mount.



Using the stock bolts, bolt the new mount to the fender. Make sure to use the rubber gasket. Feed the LED wiring down through the fender and plug into the factory license plate connectors.

3



Bolt the LED plate frame on to the mount. Don't forget your license plate. :) Check to make sure the light works. If everything is ok put the rear fender bolts in and tighten.



Install the supplied hole plug into the fender where the 3rd bolt was from the stock mount. You may want to use a touch of silicone to help hold it in.

Put the driver seat and all the covers and accessories back on. Double check all bolts for tightness.

**THANK YOU FROM
WITCHDOCTOR'S**