



**INSTALLATION OF SAE &
METRIC BOLT CAPS ON
EXISTING HEX HEAD SCREWS**

1. Align clip prongs on Hex Flats at a slight angle.
2. Push or lightly tap on Bolt-Cap.
3. Do Not Use Metal Hammer or you will damage top chrome surface.
4. To Remove: Use Pliers with Soft Jaws.